

**SERVICE MANUAL**

**MODEL 1540/1541  
DISK DRIVE**

**Preliminary**

**JAN. 1985    PN-314002-01**

 **commodore**  
**COMPUTERS**

# **SERVICE MANUAL**

## **MODEL 1540/1541 DISK DRIVE**

**Preliminary**

**JAN. 1985 PN-314002-01**

### **Commodore Business Machines, Inc.**

1200 Wilson Drive, West Chester, Pennsylvania 19380 U.S.A.

Commodore makes no expressed or implied warranties with regard to the information contained herein. The information is made available solely on an as is basis, and the entire risk as to quality and accuracy is with the user. Commodore shall not be liable for any consequential or incidental damages in connection with the use of the information contained herein. The listing of any available replacement part herein does not constitute in any case a recommendation, warranty or guaranty as to quality or suitability of such replacement part. Reproduction or use without expressed permission, of editorial or pictorial content, in any matter is prohibited.

This manual contains copyrighted and proprietary information. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Commodore Electronics Limited.

Copyright © 1985 by Commodore Electronics Limited.  
All rights reserved.

## CONTENTS

Title	Page
SPECIFICATIONS .....	1
BLOCK DIAGRAM .....	2
CARE AND MAINTENANCE .....	3
OVERVIEW .....	4
FLASH CODE .....	4
<u>CIRCUIT THEORY</u>	
POWER SUPPLY .....	5
RESET CIRCUIT .....	6
CLOCK CIRCUITS .....	7
MICROPROCESSOR CONTROL OF RAM & ROM .....	8
SERIAL INTERFACE .....	9
MICROPROCESSOR R/W AND MOTOR CONTROL LOGIC .....	10
READ/WRITE CONTROL LOGIC .....	11
READ AMPLIFIER .....	12
WRITE AMPLIFIER .....	13
POWER UP/DOWN WRITE PROTECTION .....	14
STEPPER MOTOR CONTROL CIRCUITS .....	15
SPINDLE MOTOR CONTROL CIRCUITS .....	16
TROUBLESHOOTING GUIDE .....	17
RESISTANCE CHECKS .....	19
CASEWORK/ACCESSORY PARTS LIST .....	20
MODEL IDENTIFICATION .....	21
DEVICE NUMBER CHANGE .....	21
<u>PCB ASSEMBLY 1540001</u>	
BOARD LAYOUT .....	22
PARTS LIST .....	23
PIN CONFIGURATIONS .....	25
SCHEMATIC .....	25
<u>PCB ASSEMBLY 1540048</u>	
BOARD LAYOUT .....	26
PARTS LIST .....	27
UPGRADE NOTES .....	29
SCHEMATIC .....	29

## **CONTENTS (Continued)**

<b>Title</b>		<b>Page</b>
<u>PCB ASSEMBLY 250442, 250446</u>		
BOARD LAYOUT .....		30
PARTS LIST .....		31
IC PINOUTS AND INTERNAL DIAGRAMS .....		33
SCHEMATIC .....		33
<u>POWER SUPPLY ASSEMBLY 1540002</u>		
PARTS LIST .....		34
TRANSFORMER .....		34
ASSEMBLY DRAWING .....		34
<u>ALPS DRIVE ASSEMBLY</u>		
PARTS LIST .....		35
WIRING DIAGRAM AND LAYOUT .....		35
MOTOR CONTROL PCB SCHEMATIC .....		36
<u>NEWTRONICS DRIVE ASSEMBLY</u>		
PARTS LIST .....		37
WIRING DIAGRAM AND LAYOUT .....		37
MOTOR CONTROL PCB SCHEMATIC .....		38

# **C1541 DISK DRIVE PRODUCT SPECIFICATION**

## **GENERAL DESCRIPTION**

The C1541 Disk Drive is an external 5-1/4 inch floppy diskette recorder, offering high-speed and capacity for programs and data. It is an intelligent device, containing its own microprocessor, RAM, ROM and operating systems software for faster speed of throughput and memory efficiency in the computer.

## **MAXIMUM STORAGE**

170K of data (formatted) — 35 tracks

## **MEDIA**

5-1/4 Inch floppy disk. Single sided, single density, soft sectored (double density can be used, but not needed).

## **INPUT/OUTPUT**

Commodore serial interface  
Second serial port for chaining a second drive or printer

## **CONTROLLER**

MOS 6502 microprocessor — 1 MHz clock

## **MEMORY**

2K RAM, 16K ROM

## **DATA TRANSFER RATE**

400 Bytes/sec

## **FILE TYPES**

Program, sequential, relative, random-access and user

## **NUMBER OF FILES**

Up to 144 different files per diskette

## **COMPUTERS**

C64, VIC 20, SX64, Educator 64, Plus/4, C16

## **MEDIA COMPATIBILITY**

2031, 4040, C1551


## **POWER REQUIREMENTS**

120 Volts AC, 60Hz — integral power supply with external 1 Amp fuse

## **POWER CONSUMPTION**

30 Watts maximum

# BLOCK DIAGRAM



## CARE AND MAINTENANCE

- DO NOT use MAGNETIZED tools when repairing or adjusting a disk drive.
- DO NOT place a disk drive near any device which generates "noise" e.g., — motors, radios, televisions.
- DO NOT stack drives upon each other or in any way inhibit air flow around the unit. HEAT BUILD-UP can cause disk failures.
- Periodically CLEAN the read/write head with 90% isopropyl alcohol and a cotton swab. CHECK load pad for excess wear. Clean or replace as necessary.
- Take the following precautions when handling a diskette:  
    ALWAYS store a diskette in its jacket.  
    Use ONLY felt-tip pens when writing on the label of a diskette.  
    Do not bend or physically damage a diskette.  
    Do not place a diskette in the area of a magnetic field.  
    Do not attempt to clean a diskette.  
    Do not touch the exposed area of a diskette.
- DIAGNOSTIC and ADJUSTMENT procedures are outlined in detail on the diagnostic disk (Commodore Part # 31405101). A manual has been added to the diagnostic package. It contains descriptions of testing procedures and adjustment methods.

# OVERVIEW

The drive is itself an independent memory device. The drive is composed of a media clamp rotating mechanism, a head positioning mechanism and an eject mechanism. All positioning operations, excluding insertion and removal of the diskette, are controlled by the internal guide mechanism. Closing the front door causes the media clamp mechanism to operate. Two operations are performed in the following order:

- a) The diskette is centered.
- b) The diskette is clamped and retained between the spindle and the hub.

The spindle and hub rotate at 300 r.p.m. through a closed-loop control circuit employing a D.C. motor/tachometer. It is important that the relationship between the head and the media is maintained correctly during operation. For this purpose, a pressure pad is used to hold and press down the media (about 12g) from the opposite side of the head. This head assembly is coupled by a metal band to a four phase stepping motor which performs the track positioning. One step of the stepping motor corresponds to a 1/2 track movement. The control circuit on the logic board selects the direction and number of steps to the desired track.

The Read/Write head uses a glass-bonded, ferrite/ceramic head. Track-to-track erasing is accomplished by the straddle erase method. The surface of the Read/Write head is mirror-ground to minimize wear of the head and media. Also, the head is designed in such a way that the maximum signal can be obtained from the media surface.


The spindle drive motor operates on 12 VDC and turns the spindle, through a belt drive, at 300 revolutions per minute. The speed of the drive motor is controlled by a feedback signal from a tachometer, which is housed in the drive motor assembly. The feedback signal controls a servo amp that supplies the 12 VDC drive current.

## FLASH CODE

The 1541, upon power-up, goes through its own internal diagnostic. If an electronic problem is detected, it is indicated by a FLASH CODE. The LED's will blink a set number of times, pause, and then flash again until the problem is corrected.

Number of Flashes	Possible Failure
2	Zero Page
3,4	DOS ROM's
5,6,7,8	RAM


Circuitry associated with these components can also cause the failure code. Therefore it should be suspected as the next possible defect.



All circuit diagrams have been taken from the short board schematic 1540049 unless otherwise noted. The short boards use a 6116 RAM which replaces the four 2114 I.C.s on the long board. See page 11 for the Read/Write logic differences.


### The Power Supply

The input AC voltage is controlled by switch 1 (SW1). Disk circuit protection is provided by fuse 1 (F1). If SW1 is closed the AC voltage input is applied to the primary winding of transformer one (T1). T1 steps down the AC input voltage into two smaller AC voltages. The top secondary AC output (approx. 16VRMS) is converted to DC by the Full Wave Bridge Rectifier CR1. The DC output of CR1 is regulated at 12VDC by VR1. The bottom secondary AC output of T1 (approx. 9VRMS) is converted to DC by the Full Wave Bridge Rectifier CR3. The DC output of CR3 is regulated at + 5VDC by VR2. High frequency filtering is provided by C1 and C3 for the 12VDC supply, and C4-C9, C22, C27-C30 for the 5VDC supply. Low frequency filtering is provided by C17 and C2 for the 12VDC supply, and C5 and C16 for the 5VDC supply.



### The Reset Circuit


The output of the exclusive 'or' gate UD3 pin 6 will be "low" until C46 has charged through R25. Once the voltage across C46 reaches 2 volts the output of UD3 pin 6 will go "high". This occurs when the disk is powered on, or a reset pulse was generated by a device connected to the serial bus. The reset pulse on the serial bus interface is input on pin 6 of P2 or P3. This "low" to "high" going pulse on pin 6 of UD3 is input to the microprocessors reset interrupt input. This causes a restart or reset routine to be executed giving control of the disk drive operation to the Disk Operating System (DOS).



### The Clock Circuits

Crystal Y1 outputs a 16 MHz clock signal. This is input to UD5 on pin 8. UD5 is configured as a  $\div 16$  frequency divider. The output of UD5 pin 12 is a 1 MHz clock signal used as the system clock (Phase 0) for the microprocessor. UE6 is a programmable counter ( $\div 16$ ,  $\div 15$ ,  $\div 14$ ,  $\div 13$ ) that outputs a varying frequency clock used to compensate for difference in recording area/sector for sectors on inner tracks (Trks 1,2,3) as compared to sectors on outer most tracks (Trks 33,34,35). The area/sector for inner tracks is greater than the area/sector for outer most tracks, so the recording clock frequency is increased when writing on inner tracks to keep the flux density constant. This clock output is on pin 12 of UE6.


Tracks	Clock Frequency	Divide By
1-17	1.2307 MHz	13
18-24	1.1428 MHz	14
25-30	1.0666 MHz	15
31-35	1 MHz	16



### **Micropocessor Control of RAM and ROM**


UB3 and UB4 are  $8192 \times 8$  bit Eproms that store the Disk Operating System (DOS). UB3 resides at memory locations \$C000-\$DFFF. UB4 resides at memory locations \$E000-\$FFFF. UC5 and UC6 decode the addresses output from the microprocessor when selecting these eproms.

UB2 is a  $2048 \times 8$  bit RAM. UB2 resides at memory locations \$0000-\$07FF. This memory is used for processor stack operations, general processor housekeeping, user program storage, and 4 temporary buffer areas. UC5, UC6, and UC7 decode the addresses output from the processor when selecting RAM.



## The Serial Interface

UC3 is a 6522 Versatile Interface Adapter (VIA). Two parallel ports, handshake control, programmable timers, and interrupt control are standard features of the VIA. Port B signals (PBO-PB7) control the serial interface driver IC's (UB1 and UA1). CLK and DATA signals are bidirectional signals connected to pins 4 and 5 of P2 and P3. ATN (Attention) is an input on pin 3 of P2 and P3 that is sensed at PB7 and CA1 of UC3 after being inverted by UA1. ATNA (Attention Acknowledge) is an output from PB4 of UC3 which is sensed on the data line pin 5 of P2 and P3 after being exclusively "ored" by UD3 and inverted by UB1. UC3 is selected by UC7 pin 7 going "low" when the proper address is output from the processor. UC3 resides at memory locations \$1C00-\$1C0F.




## Micropocessor R/W and Motor Control Logic

UC2 is a VIA also. During a write operation the microprocessor passes the data to be recorded to Port A of UC2. The data is then loaded into the PLA parallel port (YB0-YB7). The PLA contains a shift register which converts the parallel data into serial data. The PLA generates signals on pins 2, 3, 4, and 40 which control the write amplifiers during the write operation. During a read operation serial data is received from the read amplifier circuits on D-IN input on pin 24 of the PLA. The PLA shift register converts serial data into parallel data that is latched at the parallel port (YB0-YB7). The microprocessor reads the parallel PLA output by reading Port A of UC2 when BYTE READY on pin 39 goes "low".

The stepper motor is controlled by two outputs on port B of UC2 (STP0, and STP1). A binary four count is developed from these two lines, driving the four phases of the stepper motor. The PLA converts STP0 and STP1 into four outputs that represent one of the four states in the count (Y0,Y1,Y2,Y3). The Spindle motor is controlled by the output MTR of UC2. The PLA inverts this signal. It is then passed to the motor speed control pcb.


UC2 pin 14 is an input that monitors the state of the write protect sensor, and pin 13 is an output that controls the activity light (RED LED). UC7 decodes the addresses output from the processor when selecting UC2. UC2 resides at memory locations \$1800-\$180F."



### Read/Write Control Logic

During a write operation, UD3 converts parallel data into serial data. The output on pin 9 is input to 'NAND' gate UF5 pin 4. UF5 outputs the serial data on pin 6 at the clock rate determined by input signal on pin 5. The output clocks the D flip flop UF6. The outputs of UF6, Q and  $\overline{Q}$ , drive the write amplifiers.


During a read operation, data from the read amplifiers is applied to the CLR input of counter UF4. The outputs, C and D, are shaped by the 'NOR' gate UE5. UE5 outputs the serial data on pin 1, then it is converted to parallel data by UD2. The output of UD2 is latched by UC3. The serial bits are counted by UE3, when 8 bits have been counted, UF3 pin 12 goes "low", UC1 pin 10 goes "high", and UF3 pin 8 goes "low" indicating byte is ready to be read by the processor. UC2 monitors the parallel output of UD2, when all 8 bits are "1", the output pin 4 goes "low" indicating a sync bit has been read.




## Read Amplifier Circuits

When data is recorded on the disk, a "1" bit is represented on the disk by a change in direction of magnetic flux, caused by a change in direction of current passed through the R/W coil in the R/W head. When a "0" bit is to be recorded no change in current flow direction occurs, causing the direction of the magnetic flux to remain the same on the disk.

R/W HEAD




When data is being read from the disk, CEMF is induced into the R/W coil by the magnetic fields on the disk, causing current flow which is detected by the read amplifiers. Current flow through the R/W coil will forward bias either CR16 or CR17, depending on the direction. Q7 and CR14 must be forward biased. The 1ST amplifier UF3 senses this current flow from the R/W coil on one of the inputs and amplifies it. L9, L10, L11, L12 and C45 act as a low pass filter suppressing noise on the amplified output. UF4 is a differential amplifier which amplifies the difference of the two input signals from the filter section. UE4 is a peak detector. The output of UE4 will pulse "high" when a "1" is read. This signal is the reconstruction of data recorded. The Time Domain Filter UD4 times out when a "1" bit has been read, so unwanted "1" bits are not added to the actual data. The One Shot UD4 generates the correct data pulse width so the PLA can convert it to parallel for processor control.



### Write Amplifier Circuits

During a write operation, B must be "high". This forward biases Q7 and CR14. If  $\overline{B}$  goes "low", Q3 and Q6 become forward biased. If Q goes "low", Q5 and CR15 become forward biased, passing current flow through R/W 1. If  $\overline{Q}$  goes "low", Q4 and CR18 become forward biased, passing current flow through R/W 2.


When a write operations occurs, the ERASE coil is energized by forward biasing Q6. This demagnetizes the outer edges of the track, preventing data from one track bleeding into the next track.



#### Power Up/Down Write Protection


This circuit prevents erroneous data from being written on the disk during power up/down sequences. During a power up, the 12VDC supply is not applied to the R/W coils and amplifier circuits before the processor has control of the logic. During a power down the 12VDC supply is removed from the R/W coils and amplifier circuits before the processor loses control of the logic.

Q1 acts as a series pass transistor biased to regulate the 12VF output to the R/W coils and Amplifier circuits. Q2 is a feedback amplifier monitoring the 5VDC supply. CR5 develops a precise reference voltage for Q2. L8 and C15 delay the 12 VDC supply.



### Stepper Motor Control Circuits

Outputs Y0, Y1, Y2, and Y3 from the PLA are inverted by UD1. The outputs of the inverters drive Q8-Q11. The current output from these transistors drive the individual phase coils in the stepper motor and return to the 12VDC supply. CR8-CR11 suppress the CEMF developed by the motor coils.



### Spindle Motor Control Circuits

MTR output from the PLA is active "low". The output of UD2 goes "low". This signal is passed to motor control PCB. When MTR is "low" Q1 is reversed biased, and Q2, Q3, and A4 are forward biased allowing current flow through the spindle motor coil. Attached to shaft of the spindle motor is a inductive tachometer that generates low level AC voltages as the motor spins. The output of the tachometer is rectified by CR1-CR4. IC 1 monitors the output of the rectifier and adjusts the bias to Q2, in turn Q3 and Q4 biasing changes, causing a constant motor velocity. VR1 is a manual speed adjustment. The speed can be adjusted by watching the 60Hz strobe as the adjustment is made.

The Newtronics Motor Speed PCB is electronically the same as the ALP Motor Speed PCB, but more components have been integrated.

# TROUBLESHOOTING GUIDE




**NOTE:** Always check for latest ROM/ECO upgrade. If socketed IC is suspected bad, be sure to check socket with ohmmeter.

SYMPTOM:	POSSIBLE SOLUTION:
No LED's on power up.	Is Power cord plugged into wall outlet correctly? Is Power cord plugged into the disk drive correctly? Check line fuse. Check power switch. Check clock on 6502 pin 37. Check +5 and +12 volt lines.
Error LED flashes on power up.	Check all RAM and ROM locations.
Error LED stays on all the time.	Check 6502 microprocessor. Check ROMs.
Drive motor runs continuously and red LED stays on.	Check +12V. Check 6502, logic gates, logic array.
Drive motor runs continuously and red LED stays off.	Check Rom Check drive motor PCB.
Drive motor runs continuously with no red or green LED's.	Check VR2 (5V Regulator). Check Power Transformer.
After the drive warms up the motor runs continuously.	Check 6522s. Check motor control PCB.
Loads programs with red LED flashing.	Check drive speed. Check stepper motor.
Loading is intermittent.	Check ROMs. Check drive alignment.
Does not load when hot or LED flashed 3 times.	Check ROMs.
Searches with LED flashing continuously.	Check ROMs.
Searching with no red LED.	Check 6522s, logic gates, logic array.
Message of 'FILE NOT FOUND' is displayed.	Clean drive head w/alcohol. Check Ø stop adjustment. Check alignment.
Drive fails to read.	Check the 311, 9602, and 592s. There are two +12 volt sources for stepper output and read circuit, make sure both are good.

## **TROUBLESHOOTING GUIDE (Continued)**

<b>SYMPTOM:</b>	<b>POSSIBLE SOLUTION:</b>
Fails to format disk.	Check components related to connector P7. Check 6522s. Check logic array.
Stepper Motor does not step forward.	Check 6502, 6522s, logic array.
Drive speed will not stabilize.	Check DC motor.
Will not save when the drive heats up.	Check 6502 microprocessor.
Locks-up when loading.	Check serial port components. Check ROM.
Fails the performance test and displays a 21 read error.	Check test diskette. Check Drive Motor.
Fails the performance test and displays a 27 read error.	Check stop adjust.
Passes performance test to track 18 then displays 21 read errors.	Check read/write head.
Passes the performance test but will not load certain programs.	Check stepper motor.

# RESISTANCE CHECKS



## **CASEWORK/ACCESSORY PARTS LIST**

1540/1541	TOP CASE (IVORY) .....	1540014-01
1540/1541	BOTTOM CASE (IVORY) .....	1540015
1541	TOP CASE (BROWN) .....	1540014-03
1541	BOTTOM CASE (BROWN) .....	1540015-01
	SHIELD COVER .....	1540013-01
	LED ASSEMBLY .....	1540003
	SELF ADHESIVE FOOT .....	950150-02
1540	NAMEPLATE .....	1540016-01
1541	NAMEPLATE .....	1540052-01
	POWER CORD ASSEMBLY .....	903508-04
	6 PIN DIN CABLE .....	1540027
	USER'S MANUAL .....	1540031

**NOTE:** All 1540 Disk Drives were manufactured prior to any changes to the board and used the Alps drive exclusively.

## 1541 MODEL IDENTIFICATION

- |                       |  |
|-----------------------|--|
| PCB Assy # 1540008-01 | <ul style="list-style-type: none"><li>• Schematic # 1540001</li><li>• Original "Long" Board</li><li>• Has 4 discreet 2114 RAMs</li><li>• ALPS Drive only</li></ul>                           |
| PCB Assy # 1540048    | <ul style="list-style-type: none"><li>• Schematic # 1540049</li><li>• Referred to as the CR board</li><li>• Changed to 2048 x 8 bit RAM pkg.</li><li>• A 40 pin Gate Array is used</li></ul> |
| -01                   | <ul style="list-style-type: none"><li>• Alps Drive</li></ul>   |
| -03                   | <ul style="list-style-type: none"><li>• Newtronics Drive</li></ul>   |
| PCB Assy # 250442-01  | <ul style="list-style-type: none"><li>• Schematic # 251748</li><li>• Termed the 1541 A</li><li>• Just one jumper change to accommodate both types of drive</li></ul>                         |
| PCB Assy # 250446-01  | <ul style="list-style-type: none"><li>• Schematic # 251748 (See Notes)</li><li>• Termed the 1541 A-2</li><li>• Just one jumper change to accommodate both types of drive</li></ul>           |

**NOTE:** The simplest way to identify which drive you have is by the door assembly. Alps is made with a "push down" door and Newtronics has a "flipper" type door.

## DEVICE NUMBER CHANGE


The 1540 and 1541 drives are shipped from the factory set for device # 8. The channel can be hardware altered to # 9, 10, or 11 by two methods:

- 1) Refer to appropriate board layout drawing for the location of the pads provided for this purpose. The device change pads must be CUT to alter the channel number and re-soldered if another change is needed later.
- 2) The preferred method to alter the device number is to lift certain pins of the 6522 chip. The I.C. should always be socketed, so removal of the chip is simple. Once removed, the proper pin can be carefully bent to eliminate it from the circuit. If another change is needed, simply remove the I.C. and re-install with the pin back in place.

PCB ASSY #	LOCATION	DEVICE #	LIFT PIN
1540008	UAB1	9	15
1540048, 251748 and 251834	UC3	10	16
	UC3	11	15 and 16

# **PCB ASSEMBLY #1540001**

## **BOARD LAYOUT**



DEVICE NUMBER  
PAD LOCATION

# PARTS LIST

## PCB ASSEMBLY #1540001

### **PLEASE NOTE:**

Commodore part numbers are provided for reference only and do not indicate the availability of parts from Commodore. Industry standard parts (Resistors, Capacitors, Connectors) should be secured locally. Approved cross-references for TTL chips, Transistors, etc. will be available in manual form through the Service Department in November of 1984. Unique or non-standard parts will be stocked by Commodore and are indicated on the parts list by a "C".

<b>INTEGRATED CIRCUITS</b>			<b>DIODES</b>		
UAB1	6522 VIA	C 901437-01	CR1	Bridge, 1.5A, 50V	900756-01
UAB2	6114 RAM	901471-01	CR2	Rectifier, IN4002	900750-02
UAB3	6114 RAM	901471-01	CR3	Bridge, 4A, 50V	900755-02
UAB4	ROM \$C000-\$FFFF	C 325302-01	CR4	Rectifier, IN4002	900750-02
UAB5	ROM \$E000-\$FFFF (1540)	C 325303-01	CR5	Zener, 3.3V, 500mW, +/- 5%	
UAB5	ROM \$E000-\$FFFF (1541)	C 901229-07		HZ3C-2	325505-01 sub:
UB2	6114 RAM	901471-01		HZ4A-1	325505-02 sub:
UB3	6114 RAM	901471-01		IN5226B	900948-06
UCD4	6522 VIA	C 901437-01	CR6-11	Signal, WG713C	900850-05 sub:
UCD5	6502 CPU	C 901435-01		IN4148	900850-01
UG3	9602	901510-01	CR12	Zener, 5.1V, 500mW, +/- 5%	
UH4	LM311	901523-04		HZ5C-2	325506-01 sub:
UH5	NE 592	901523-08		IN5231	900948-11
UH7	NE 592	901523-08	CR13-16	Rectifier, IN4002	900750-02
				Signal, WG713C	900850-05 Sub:
				IN4148	900850-01
<b>TTL</b>			<b>RESISTORS</b> — All Values are in ohms- 1/4 W 5% unless noted otherwise.		
UB6	74LS04	901521-02	R1, 2	330	
UB7	74LS00	901521-01	R3	47	
UB8	74LS42	901521-17	R4	220	
UC1	74LS14	901521-30	R5	330	
UC2	74LS133	901521-15	R6	1K	
UC3	74LS245	901521-45	R7	22K	
UC6	74177	901522-03 sub: 74LS197	R8	91, Metal Oxide 1/4W, 1%	
		901521-54	R9	680	
UC7	7402	901522-32	R10	22K	
UD1	7406	901522-06	R11	1K	
UD2	74LS164	901521-28	R12, 13	9.1K, Metal Oxide 1/4W, 1%	
UD3	74LS165	901521-12	R14, 15	2.2K	
UE2	74LS139	901521-18	R16, 17	220	
UE3	74LS191	901521-40	R18, 19	150	
UE4	74LS74	901521-06	R20	330	
UE5	74LS02	901521-21	R21-23	2K	
UE7	74LS193	901521-26	R24	510	
UF2	7406	901522-06	R25	360	
UF3	74LS10	901521-24	R26	5.1K	
UF4	74LS193	901521-26	R27, 28	470	
UF5	74LS00	901521-01	R29	22K	
UF6	74LS74	901521-06	R30	360	
UG2	74LS86	901521-32	R31-34	1K	
UG4	7417	901522-01 sub: 7407	R35, 36	100	
		901522-30	R37	330	
<b>TRANSISTORS</b>			R38	2K	
Q1	2SA673 PNP	902720-01	R39-42	680	
Q2, 3	2SC945 NPN	902671-01 sub: 2SC1815 NPN	R43	6.8K	
Q4, 7	2SD467 NPN	902679-01 sub: 2SC2120 NPN	R44	1K	
Q8-11	2SA733 PNP	902682-01 sub: 2SA1015 PNP	R45	220	
		902717-01 sub: 902744-01	R46	100K	


**PARTS LIST PCB ASSEMBLY #1540001 (Continued)**

**C - Indicates Commodore Stocked Part Number**


<b>RESISTORS (Continued)</b>		<b>CAPACITORS (Continued)</b>	
— All values are in ohms- 1/4 W 5% unless noted otherwise.			
R47	470	C51	Electrolytic      6800µF, 25V
R48	1.5K	C52	Electrolytic      10000µF, 16V
R49	100, Metal Oxide 1/4W, 1%	C53-55	Ceramic      .1µF, 50V
R50	470	C56	Electrolytic      100µF, 16V
R51, 52	2.2K	C57	Ceramic      .1µF, 50V
R53	22K	C58, 59	Ceramic      .022µF, 16V
R54	150, Metal Oxide 1/4W, 1%	C60, 61	Ceramic      .1µF, 50V
R55	470	C62	Tantalum      4.7µF, 25V
R56	2.2K	C63	Tantalum      1µF, 35V
R57	470	C64	Ceramic      .033µF, 25V
R58	1K	C65	Electrolytic      220µF, 25V
R59	220	<b>MISCELLANEOUS</b>	
<b>CAPACITORS</b>		L1	Coil Inductor 2.2µH
C1	Electrolytic      1µF, 25V	L2-6	Ferrite Bead (2743005112)
C2	Electrolytic      47µF, 16V	L7	Coil Inductor 100µH
C3	Ceramic      .1µF, 50V	L8	Coil Inductor 22µH
C4	Electrolytic      1µF, 25V	L9, 10	Coil Inductor 100µH
C5	Electrolytic      47µF, 16V	L11	Coil Inductor 22µH
C6-9	Ceramic      .1µF, 50V	L12-16	Ferrite Bead (2743005112)
C10	Ceramic      68pF, 50V	VR1	Voltage Reg 12V, 1.5A (LM340K-12 TO-3)
C11	Ceramic      .1µF, 50V	VR2	Voltage Reg 5V, 1.2A (LM340K-5 TO-3) Sub: 5V, 3A (LM323)
C12	Tantalum      10µF, 25V	Y1	Crystal 16MHz      900556-02 Shield Box      4022048-01 Shield Cap      4022047-01
C13, 14	Ceramic      .1µF, 50V	<b>CONNECTORS</b>	
C15	Tantalum      .47µF, 16V +/- 20%	P1	Header Assy, 3.96 Pitch, 4Pin      (Molex 5271-04A)
C16	Ceramic      680 pF, 50V +/- 5%	P2, 3	6 Pin Din, (Hoshidenki TSC4460-01-101      C 903361-01
C17-22	Ceramic      .1µF, 50V	P4, 5	Header Assy, 2.5 Pitch, 3Pin      (Molex 3022-03A)
C23	Tantalum      3.3µF, 25V	P6	Header Assy, 2.5 Pitch, 15Pin      (Molex 3022-15A)
C24	Tantalum      .47µF, 16V +/- 20%	P7	Header Assy, 2.5 Pitch, 6Pin      (Molex 3022-06A)
C25	Ceramic      .1µF, 50V	P8	Header Assy, 2.5 Pitch, 4Pin      (Molex 5048-04AG)
C26	Ceramic      1000pF, 50V		
C27	Ceramic      680pF, 50V +/- 5%		
C28	Ceramic      330pF, 50V +/- 5%		
C29-32	Ceramic      .1µF, 50V		
C33	Ceramic      33pF, 50V		
C34-48	Ceramic      .1µF, 50V		
C49	Ceramic      330pF, 50V +/- 5%		
C50	Ceramic      680pF, 50V +/- 5%		

**SCHEMATIC #1540008**

## **PIN CONFIGURATIONS:**





**901435-01**  
**Microprocessor**




## **2048 X 8 STATIC RAM**

Approved Replacements	
Mitsubishi	M58725P
Toshiba	TMM2016P
Hitachi	HM6116LP-4/AP-20



**PCB ASSY #1540048**  
**BOARD LAYOUT**



# PARTS LIST

## PCB ASSEMBLY #1540048

### **PLEASE NOTE:**

Commodore part numbers are provided for reference only and do not indicate the availability of parts from Commodore. Industry standard parts (Resistors, Capacitors, Connectors) should be secured locally. Approved cross-references for TTL chips, Transistors, etc. will be available in manual form through the Service Department in November of 1984. Unique or non-standard parts will be stocked by Commodore and are indicated on the parts list by a "C".

<b>INTEGRATED CIRCUITS</b>			<b>DIODES</b>			
UB2	TMM2016P RAM	325502-03	sub:	CR1	Bridge, 1.5A, 50V	
	M58725P RAM	325502-01	sub:	CR2	Rectifier, IN4002	
	HM6116P4	325502-08		CR3	Bridge, 1.5A, 50V	
UB3	ROM \$C000-\$FFFF	C 325302-01		CR4	Rectifier, IN4002	
UB4	ROM \$E000-\$FFFF	C 901229-05		CR5	Zener, 3.3V, 500mW, +/- 5%	
UC1	GATE ARRAY	325572-01			HZ3C-2	
UC2	6522 VIA	C 901437-01			HZ4A-1	
UC3	6522 VIA	C 901437-01			IN5226B	
UC4	6502 CPU	C 901435-01		CR6, 7	Signal, WG713C	
UD4	9602	901510-01			IN4148	
UE4	LM311	901523-04		CR8-11	Rectifier, IN4002	
UF3	NE 592	901523-08		CR12	Signal, WG713C	
UF4	NE 592	901523-08		CR13	Zener, 5.1V, 500mW, +/- 5%	
<b>TTL</b>					HZ5C-2	
UA1	74LS14	901521-30			IN5231	
UB1	7406	901522-06	sub:	CR14-18	Signal, WG713C	
	7707	251749-01			IN4148	
UC5	74LS04	901521-02	sub:	<b>RESISTORS</b> — All Values are in ohms- 1/4 W 5% unless noted otherwise.		
	7713	251749-02	sub:	R1	47	
	74LS14	901521-30	sub:	R2	1K	
	7414	901522-19		R3	330	
UC6	74LS00	901521-01		R4	220	
UC7	74LS42	901521-17		R5-8	1K	
UD1	7406	901522-06		R9, 10	2K	
UD2	7417	901522-01	sub:	R11	5.1K	
	7407	901522-30		R12	22K	
UD3	74LS86	901521-32		R14	360	
UD5	74LS197	901521-54	sub:	R16	220	
	74177	901522-03		R17, 18	150	
UE6	74LS193	901521-26		R19	2.2K	
<b>TRANSISTORS</b>				R20	470	
Q1	2SA673 PNP	902720-01		R21	2.2K	
Q2	2SC945 NPN	902671-01	sub:	R22	470	
	2SC1815 NPN	902693-01		R23	330	
Q3-6	2SA733 PNP	902717-01	sub:	R24	360	
	2SA1015 PNP	902744-01		R25	6.8K	
Q7	2SC945 NPN	902671-01	sub:	R26	2K	
	2SC1815 NPN	902693-01		R27	510	
Q8-11	2SD467 NPN	902679-01	sub:	R28	100 @ 1%	
	2SC2120 NPN	902682-01			150 @ 1% (ALPS)	
					137 @ 1% (NEWTRONICS)	

**PARTS LIST PCB ASSEMBLY #1540048 (Continued)**

**C - Indicates Commodore Stocked Part Number**

<b>RESISTORS (Continued)</b>		<b>CAPACITORS (Continued)</b>		
— All Values are in ohms- 1/4 W 5% unless noted otherwise.				
R40	1.5K	C39	Ceramic	.022μF, 16V
R41	470	C40	Ceramic	.1μF, 50V
R42	680	C41	Ceramic	1000pF, 50V
R43	1K	C42	Ceramic	.022μF, 16V
R44	100K	C43	Ceramic	.1μF, 50V
R45, 46	150	C44	Tantalum	3.3μF, 25V
R47-50	680	C45	Ceramic	680pF, 50V +/- 5%
R51	91 @ 1% (ALPS)	C46	Electrolytic	100μF, 16V
	56 @ 1% (NEWTRONICS)	C47, 48	Ceramic	.1μF, 50V
R52	22K	<b>MISCELLANEOUS</b>		
R53, 54	9.1K @ 1%	L1	Coil Inductor 2.2μH	
R55	220	L2-7	Ferrite Bead (2743005112)	
R57	220	L8	Coil Inductor 100μH	
R58	2K	L9, 10	Coil Inductor 22μH	
<b>CAPACITORS</b>		L11, 12	Coil Inductor 100μH	
C1	Electrolytic	L13-16	Ferrite Bead	
C2	Electrolytic	VR1	Voltage Reg 12V, 1.5A (LM340K-12 TO-3)	
C3	Ceramic	VR2	Voltage Reg 5V, 1.2A (LM340K-5 TO-3) Sub: 5V, 3A (LM323)	
C4	Electrolytic	Y1	Crystal Module 16MHz 50ppm (NDK, Tyocom) Sub: 16MHz 100ppm (NDK, Tyocom, Kyocera)	
C5	Electrolytic		Shield Box C 4022048-01	
C6-10	Ceramic		Shield Cap C 4022047-01	
C11	Tantalum	<b>CONNECTORS</b>		
C12	Ceramic	P1	Header Assy, 3.96 Pitch, 4Pin	(Molex 5271-04A)
C13	Electrolytic	P2, 3	6 Pin Din,	C 903361-01
C14	Ceramic	P4, 5	Header Assy, 2.5 Pitch, 3Pin	(Molex 3022-03A)
C15	Tantalum	P6	Header Assy, 2.5 Pitch, 15Pin	(Molex 3022-15A)
C16	Electrolytic	P7	Header Assy, 2.5 Pitch, 6Pin	(Molex 3022-06A)
C17	Electrolytic	P8	Header Assy, 2.5 Pitch, 4Pin	(Molex 5048-04AG)
C18-20	Ceramic			
C21	Tantalum			
C22-30	Ceramic			
C31	Ceramic			
C32	Ceramic			
C33, 34	Ceramic			
C35	Ceramic			
C36	Ceramic			
C37-38	Tantalum			


## UPGRADE NOTES

PCB Assembly # 1540048 (Schematic 1540049) requires an upgrade to the reset circuit. The upgrade consists of:

## 1) COMPONENT CHANGES:

- R25 Change To 6.8K ohm, 1/4 W, +/−5%
- R57 Add 220 ohm, 1/4 W, +/−5%
- R58 Add 2K ohm, 1/4 W, +/−5%


## 2) CUT circuit trace near UA1 (See diagram)



## 3) INSTALL JUMPER WIRES:



- BETWEEN: UA1 pin 8 and UB1 pin 5
- UA1 pin 9 and CR7 Anode
- UB1 pin 6 and UD3 pin 5 on BACK of board

## 4) CUT circuit trace between CR7 Anode and UD3 pin 5 on BACK of board.



# PCB ASSEMBLY #250442/46

## BOARD LAYOUT



SUBSTITUTE HEATSINK

# PARTS LIST

## PCB ASSEMBLY #250442/46

### PLEASE NOTE:


Commodore part numbers are provided for reference only and do not indicate the availability of parts from Commodore. Industry standard parts (Resistors, Capacitors, Connectors) should be secured locally. Approved cross-references for TTL chips, Transistors, etc. will be available in manual form through the Service Department in November of 1984. Unique or non-standard parts will be stocked by Commodore and are indicated on the parts list by a "C".

INTEGRATED CIRCUITS				DIODES (Continued)		
UB2	TMM2016P RAM M58725P RAM HM6116P4	325502-03 325502-01 325502-08	sub: sub: sub:	CR6, 7	Signal, WG713C IN4148	900850-05 sub: 900850-01
UB3	ROM \$C000-\$FFFF	C 325302-01		CR8-11	Rectifier, IN4002	900750-02
UB4	ROM \$E000-\$FFFF	C 901229-05		CR12	Signal, WG713C IN4148	900850-05 sub: 900850-01
UC1	GATE ARRAY	325572-01		CR13	Zener, 5.1V, 500mW, +/- 5% HZ5C-2	325506-01 sub: 900948-11
UC2	6522 VIA	C 901437-01		CR14-18	IN5231	900850-05 Sub: 900850-01
UC3	6522 VIA	C 901437-01			Signal, WG713C IN4148	900850-05 Sub: 900850-01
UC4	6502 CPU	C 901435-01				
UD4	9602 (250442) 74LS123 (250446)	901510-01 901521-49	sub:			
UE4	LM311	901523-04				
UF3	NE 592	901523-08				
UF4	NE 592	901523-08				
TTL				RESISTORS — All values are in ohms- 1/4 W 5% unless noted otherwise.		
UA1	74LS14	901521-30		R1	47	
UB1	7406	901522-06	sub:	R2	1K	
	74LS06	901521-73		R3	330	
UC5	74LS04	901521-02	sub:	R4	220	
	74LS14	901521-30	sub:	R5-8	1K	
	7414	901522-19		R9, 10	2K	
UC7	74LS00	901521-01		R11	5.1K	
UC8	74LS42	901521-17		R12	22K (250442)	
UD1	7406	901522-06	sub:	R14	15K	
	74LS06	901521-73		R16	360 (250446)	
UD2	7417	901522-01	sub:	R17, 18	220	
	7407	901522-30		R19	150	
UD3	74LS86	901521-32		R20	2.2K	
UD5	74LS197	901521-54	sub:	R21	470	
	74177	901522-03		R22	2.2K	
UE6	74LS193	901521-26		R23	470	
				R24	330	
				R25	360	
				R26	6.8K	
				R27	2K	
				R28	510	
				R29	100 @ 1%	
				R30	137 @ 1%	
				R31	470	
				R32-34	680	
Q1	2SA673 PNP	902720-01		R35	2.2K	
Q2	2SC945 NPN	902671-01	sub:	R36	22K	
	2SC1815 NPN	902693-01		R37, 38	220	
Q3-6	2SA733 PNP	902717-01	sub:	R39	470	
	2SA1015 PNP	902744-01		R40	22K	
Q7	2SC945 NPN	902671-01	sub:	R41	1.5K	
	2SC1815 NPN	902693-01		R42	470	
Q8-11	2SD467 NPN	902679-01	sub:	R43	680	
	2SC2120 NPN	902682-01		R44	1K	
				R45, 46	100K	
				R47-50	150	
				R51	680	
				R52	56 @ 1%	
CR1	Bridge, 1.5A, 50V	900756-01		R53, 54	22K	
CR2	Rectifier, IN4002	900750-02		R55	10K	
CR3	Bridge, 1.5A, 50V	900756-01		R56	220	
CR4	Rectifier, IN4002	900750-02		R57	220	
CR5	Zener, 3.3V, 500mW, +/- 5% HZ3C-2	325505-01	sub:	R58	13 @ 1%	
	HZ4A-1	325505-02	sub:			
	IN5226B	900948-06				



**PARTS LIST PCB ASSEMBLY #250442/46 (Continued)**

**C - Indicates Commodore Stocked Part Number**

<b>CAPACITORS</b>			<b>MISCELLANEOUS</b>		
C1	Electrolytic	.1µF, 25V	L1	Coil Inductor 2.2µH	
C2	Electrolytic	47µF, 16V	L2-7	Ferrite Bead (2743005112)	
C3	Ceramic	.1µF, 50V	L8	Coil Inductor 100µH	
C4	Electrolytic	.1µF, 25V	L9, 10	Coil Inductor 22µH	
C5	Electrolytic	47µF, 16V	L11, 12	Coil Inductor 100µH	
C6-10	Ceramic	.1µF, 50V			
C11	Tantalium	.1µF, 35V	VR1	Voltage Reg 12V, 1.5A (LM340K-12 TO-3)	
C12	Ceramic	.033µF, 25V	VR2	Voltage Reg 5V, 1.2A (LM340K-5 TO-3) Sub: 5V, 3A (LM323)	
C13	Electrolytic	220µF, 10V			
C14	Ceramic	.1µF, 50V	Y1	Crystal Module 16MHz 50ppm (NDK, Tyocom) Sub: 16MHz 100ppm (NDK, Tyocom, Kyocera)	
C15	Tantalium	10µF, 25V			
C16	Electrolytic	4700µF, 16V			
C17	Electrolytic	6800µF, 25V			
C18-20	Ceramic	.1µF, 50V			
C21	Tantalium	4.7µF, 25V			
C22-30	Ceramic	.1µF, 50V	P1	Header Assy, 3.96 Pitch, 4Pin	(Molex 5271-04A)
C31	Ceramic	33pF, 50V +/-5%	P2, 3	6 Pin Din,	C 903361-01
C32	Ceramic	330pF, 50V +/-5%	P4, 5	Header Assy, 2.5 Pitch, 3Pin	(Molex 3022-03A)
C33, 34	Ceramic	680pF, 50V +/-5%	P6	Header Assy, 2.5 Pitch, 15Pin	(Molex 3022-15A)
C35	Ceramic	.1µF, 50V	P7	Header Assy, 2.5 Pitch, 6Pin	(Molex 3022-06A)
C36	Ceramic	330pF, 50V +/-5%	P8	Header Assy, 2.5 Pitch, 4Pin	(Molex 5048-04AG)
C37-38	Tantalium	.47µF, 16V			
C39	Ceramic	.022µF, 16V			
C40	Ceramic	.1µF, 50V			
C41	Ceramic	1000pF, 50V			
C42	Ceramic	.022µF, 16V			
C43	Ceramic	.1µF, 50V			
C44	Tantalium	3.3µF, 25V			
C45	Ceramic	680pF, 50V +/-5%			
C46	Electrolytic	100µF, 16V			
C47, 48	Ceramic	.1µF, 50V			



**PN 325572  
GATE ARRAY FOR FLOPPY  
DISK DRIVE**



**SCHEMATIC NOTE:**

Schematic # 251748 can be used for two board assembly numbers. The changes for each assembly number are:

Component	PCB Assy #250442	PCB Assy #250446
UD4	9602	74LS123
R12	22K	15K
C31	33pF	Eliminated


**POWER SUPPLY  
#1540002**

**1540/1541 POWER SUPPLY ASSEMBLY  
PARTS LIST**


FUSE HOLDER  
ROCKER SWITCH  
POWER CNNCT FILTER

FUSE, NORMAL BLO, 250V, 1.0A  
POWER TRANSFORMER

903614-01  
904509-01  
903467-03 sub:  
325552-01  
903556-16  
1540009-02



**TRANSFORMER**



**ASSEMBLY DRAWING**

# ALPS DRIVE ASSEMBLIES


## 1540/1541

### PARTS LIST


**32551901 Alps Drive (Black)**

**32551902 Alps Drive (Brown)**



- |   |   |
|---|---|
| (1) 31410001 ALP DOOR/HUB ASSEMBLY<br>1-Door Assy w/Spring<br>2-Hub/Collet Assy<br>3-Arm Support Assy         | (7) 31410701 ALP MOTOR CONTROL PCB ASSEMBLY<br>1-Motor Control PCB<br>2-Harness Assy                |
| (2) 31410101 ALP LEFT DISK GUIDE ASSEMBLY<br>1-Diskette Guide<br>2-LED Assy w/Harness<br>3-Write Protect Assy | (8) 31410801 ALP TENSION PULLEY ASSEMBLY<br>1-Pulley Wheel w/Spring<br>2-Plastic Housing            |
| (3) 31410201 ALP RIGHT DISK GUIDE   | (9) 31410901 ALP HOUSING/SPINDLE ASSEMBLY<br>1-Housing Base<br>2-Spindle Assy<br>3-L/R Guide Shafts |
| (4) 31410301 ALP FRONT BEZEL (Black)<br><br>31410302 ALP FRONT BEZEL (Brown)                                  | 31411001 ALP DRIVE BELT   |
| (5) 31410401 ALP R/W HEAD ASSEMBLY<br>1-R/W Head<br>2-Load Arm w/Pad<br>3-Metal Band                          | (10) 31411101 ALP EJECT ASSEMBLY<br>1-Eject Plate<br>2-Eject Spring                                 |
| 31410501 ALP STEPPER MOTOR ASSEMBLY<br>1-Stepper Motor w/Harness<br>2-Stepper Pulley                          | 31411201 ALP HARDWARE<br>1-Assorted Screws<br>2-Zero Stop Tab                                       |
| (6) 31410601 ALP D.C. MOTOR   | 31417401 UNIV Replacement Load Pad  |




READ/WRITE HEAD ASSEMBLY



MOTOR CONTROL P.C.B.



## ALPS MOTOR CONTROL BOARD SCHEMATIC



<u>SYMBOL</u>	<u>DESCRIPTION</u>
I.C.	Sony CX-065B
Q1	Transistor 2SC2785
Q2	Transistor 2SC2785
Q3	Transistor 2SA1175
Q4	Transistor B703-B36E
CR1,2,3,4,5	Diode IN4148
R1,7	Resistor, 1kΩ, 1/4W
R2	Resistor, 68kΩ, 1/4W
R3	Resistor, 220Ω, 1/4W
R4	Resistor, 3.3kΩ, 1/4W
R5	Resistor, 2.7kΩ, 1/4W
R6	Resistor, 820Ω, 1/4W
R8	Resistor, 150Ω, 1/4W
R9	Resistor, 0.68Ω, 2W
R10	Resistor, 5.1k $\mu$ , 1/8W
VR1	Variable Resistor, 20kΩ
C1,5,6	Capacitor, Electrolytic, 10 $\mu$ F, 35V
C2	Capacitor, 0.0047 $\mu$ F, 50V
C3	Capacitor, 0.033 $\mu$ F, 50V
C4,9	Capacitor, Tantalum, 0.47 $\mu$ F, 35V
C7	Capacitor, Tantalum, 2.2 $\mu$ F, 16V
C8	Capacitor, 0.068 $\mu$ F, 50V

**PARTS LIST**

#251643-01 NEWTRONICS DRIVE (Brown)

#251643-02 NEWTRONICS DRIVE (Dk. Grey)

- ① 314120-01 NWT DOOR/LATCH ASSEMBLY  
1-Top Plate w/Latch Spring & Cam  
2-Latch Knob w/Allen Screws

- ② 314121-01 NWT HUB FRAME ASSEMBLY  
1-Hub/Collet Assy  
2-Hub Frame

- ③ 314122-01 NWT FRONT BEZEL ASSEMBLY  
1-Front Bezel w/LED & Harness  
2-Write Protect Assy

- ④ 314123-01 NWT R/W HEAD ASSEMBLY  
1-R/W Head  
2-Load Arm w/Pad  
3-Metal Band

- 314124-01 NWT STEPPER MOTOR ASSEMBLY  
1-Stepper Motor w/Harness  
2-Stepper Pulley

- ⑤ 314125-01 NWT D.C. MOTOR


- ⑥ 314126-01 NWT MOTOR CONTROL PCB ASSEMBLY  
1-Motor Control PCB  
2-Harness Assy

- ⑦ 314127-01 NWT HOUSING SPINDLE ASSEMBLY  
1-Housing Base  
2-Spindle Assy  
3-L/R Guide Shafts  
4-Brass Pulley


314128-01 NWT DRIVE BELT

314129-01 NWT HARDWARE  
1-Assorted Screws  
2-Zero Stop Tab  
3-Tension Spring

314174-01 UNIV Replacement Load Pad



# **NEWTRONICS MOTOR CONTROL SCHEMATIC**



**DOCUMENT REGISTRATION**

Date: \_\_\_\_\_

Manual Name: \_\_\_\_\_

Part Number: \_\_\_\_\_

Issue Date: \_\_\_\_\_

The return of this information is essential to the maintenance of your documentation. If necessary, document updates and changes will be distributed to registered persons. Subsequent versions and editions of this document must be purchased.

Name: \_\_\_\_\_

Company: \_\_\_\_\_

Street: \_\_\_\_\_

City: \_\_\_\_\_ State: \_\_\_\_\_ Zip: \_\_\_\_\_

Tear Here

PLACE  
STAMP  
HERE

COMMODORE BUSINESS MACHINES  
C-2654  
West Chester, PA 19380

Service Documentation



## DOCUMENT CHANGE RECOMMENDATION

THIS FORM PROVIDES OUR CUSTOMERS WITH AN EASY METHOD OF SENDING IN DOCUMENT CHANGE RECOMMENDATIONS. JUST REMOVE, FILL IN, AND MAIL THIS FORM. OUR STAFF WILL REVIEW ALL RECOMMENDATIONS AND, WHEN APPROPRIATE, MAKE THE CHANGES TO THE DOCUMENT. THANK YOU FOR YOUR COMMENTS.

DOCUMENT PART NUMBER, TITLE, DATE OF ISSUE:

USER'S EVALUATION OF MANUAL: Check Appropriate Block(s)

Excellent       Good       Fair       Poor       Complete       Incomplete

REASON FOR CHANGE RECOMMENDATIONS:

To correct error;  To improve content;  To improve quality;  Other (indicate below)

PAGE, PARAGRAPH, OR DRAWING AFFECTED BY RECOMMENDATION:

DETAILS:

FOLD  
1

FOLD  
2

ZIP

STATE

CITY:

STREET:

PHONE:

COMPANY:

DATE:

NAME:

PLACE  
STAMP  
HERE

COMMODORE BUSINESS MACHINES  
C-2654  
West Chester, PA 19380

**Service Documentation**



Computer Systems Division  
1200 Wilson Drive  
West Chester, PA 19380